

## GRIDSMART DATA MODULES

FEATURE	Performance Module	Performance Plus Module
<b>Client Reports</b>		
<b>Standard Reports</b>		
Volume	X	X
Turning Movement Count	X	X
Vehicle Classification	X	X
Incident	X	X
Raw Export	X	X
<b>Performance Reports</b>		
Seven Day Volume	X	X
Green Occupancy	X	X
Red Occupancy	X	X
Percent Arrivals on Green	X	X
Percent Arrivals on Red	X	X
Speed	X	X
<b>Auto Reports</b>	X <sup>1</sup>	X <sup>3</sup>
<b>GRIDSMART.cloud Reports</b>	X <sup>1</sup>	X <sup>3</sup>
<b>Alerts<sup>2</sup></b>		
All System Events	X <sup>1</sup>	X <sup>3</sup>
Loss of Visibility		X <sup>3</sup>
Volume Exceeded		X <sup>3</sup>
Loss of Green (Flash)		X <sup>3</sup>
Zone Activated		X <sup>3</sup>
<b>H.264 Streams</b>		X <sup>1,4</sup>
<b>Minute by Minute Display</b>	X <sup>1</sup>	X <sup>1</sup>
<b>Vulnerable Road Users</b>		
Pedestrian Crosswalk Detection		X <sup>4</sup>
Bicycle Clearance Extensions		X <sup>4</sup>

## DESCRIPTIONS OF ALERTS

All System Events	On system events such as Publish, Startup, IP address change, Camera Offline/Online.
Loss of Visibility	When the camera visibility is lost for any zone. Includes snapshot.
Volume Exceeded	When the site volume exceeds a set amount.
Flash (Loss of Greens)	When the intersection is suspected to be in flash.
Zone Activated	When a zone is activated. Can be used for wrong-way detection.

## KEY

- 1 Requires WAN connectivity
- 2 Alerts are delivered via email upon occurrence. Events shown in GRIDSMART.cloud are updated once daily, not upon occurrence.
- 3 Requires External Antenna or WAN connectivity
- 4 Requires GS<sub>2</sub>