

 [Click here to print a copy of this document in PDF format.](#)

TecNote 2004 – Upgrading to a Paging System

The Chronomax pager system was designed to permit existing Chronomax users to easily upgrade to a school zone pager system. The procedure is simple. It merely involves installing a mounting bracket with pager, changing the time switch PROM, and connecting a few cables. However, do not allow the simplicity of the procedure to encourage short cuts. This entire document should be carefully read prior to attempting an installation. It will assist you in selecting your tools, and make you aware of issues that need to be resolved before you go to the field.

Included Parts

The following parts are included with the upgrade kit:

- Pager Module
- Pager Mounting Bracket
- "Puck" Antenna with Coax
- Time Switch Upgrade PROM

Required Equipment

- Flat-Head Screwdriver (for removing time clock face plate)
- Small Flat-Head Screwdriver (for removing time clock LCD)
- Drill
- Drill Bit (for drilling hole in back panel)
- Drill Bit (for drilling hole in cabinet roof)
- Adjustable Wrench (for holding nuts in place)

Print

If you are running Microsoft Internet Explorer, you can [this page here](#).

Otherwise, print a copy of the document using the PDF file at the beginning of this page



© Copyright 2000 by Naztec, Inc - All Rights Reserved

No part of this html page may be copied, reproduced, distributed, resold, translated, or reduced to any medium or form without the express consent of Naztec, Inc.

The Technology That Moves America

Naztec, Inc
820 Park Two Dr.
Sugar Land, TX 77478, USA.

(281) 240-7233 (FAX) 240-7238
Email: naztec@naztec.com
